

Plant Drwy from Quam Siteplan

Recon Outlet need to cut about 1-1/2 ft to drain to west (river)

Add 18" Culvert

Install inlet pairs

24" Cross Pipe Ok



